

負荷DMX対応表

龍ヶ崎市文化会館

DMX No	負荷名称	回路番号	DMX No	負荷名称	回路番号	DMX No	負荷名称	回路番号	DMX No	負荷名称	回路番号	DMX No	負荷名称	回路番号	DMX No	負荷名称	回路番号
1	1B上下 W	1	41	2S	1	81	UH 78	5	121	1CL	7	162	FC上	3	204	天反	1
2	1B上下 W	2	42	2S	2	82	UH 22	6	122	1CL	8	163	FC上	4	205		2
3	1B上下 72	3	43	2S	3	83	UH 71	7	123	1CL	9	164	FC上	5	206		3
4	1B上下 78	4	44	2S	4	84	UH 52	8	124	1CL	10	165	FC上	6	207		4
5	1B中 W	1	45	2S	5	85	UH 72	9	125	1CL	11	166	FC上	7	208		5
6	1B中 W	2	46	2S	6	86	UH 63	10	126	1CL	12	167	FC上	8	209		6
7	1B中 72	3	47	2S	7	87	UH 78	11	127	1CL	13	168	FC上	9	210		7
8	1B中 78	4	48	2S	8	88	UH 22	12	128	1CL	14	169	FC上	10	211		8
9	2B上下 W	1	49	2S	9	89	LH 72	1	129	1CL	15	170	FC上	11	212		
10	2B上下 W	2	50	2S	10	90	LH 59	2	130	1CL	16	171	FC上	12	213		
11	2B上下 72	3	51	2S	11	91	LH 22	3	131	1CL	17	172	FC上	13	214		
12	2B上下 78	4	52	2S	12	92	LH 40	4	132	2CL	1	173	FC上	14	215	客1	1
13	2B中 W	1	53	2S	13	93	LH 72	5	133	2CL	2	174	FC上	15	216		2
14	2B中 W	2	54	2S	14	94	LH 59	6	134	2CL	3	175	FC上	16	217		3
15	2B中 72	3	55	2S	15	95	LH 22	7	135	2CL	4	176	FCT	1	218		4
16	2B中 78	4	56	2S	16	96	LH 40	8	136	2CL	5	177	FCT	2	219		5
17	3B上下 W	1	57	3S	1	97	LH 72	9	137	2CL	6	178	FCT	3	220	客2	1
18	3B上下 W	2	58	3S	2	98	LH 59	10	138	2CL	7	179	FCT	4	221		2
19	3B上下 72	3	59	3S	3	99	LH 22	11	139	2CL	8	180	FCT	5	222		3
20	3B上下 78	4	60	3S	4	100	LH 40	12	140	2CL	9	181	FCT	6	223		4
21	3B中 W	1	61	3S	5	101	FS上	1	141	2CL	10	182	FCT	7	224		5
22	3B中 W	2	62	3S	6	102	FS上	2	142	2CL	11	183	FCT	8	225	客3	1
23	3B中 72	3	63	3S	7	103	FS上	3	143	2CL	12	184	FCT	9	226		2
24	3B中 78	4	64	3S	8	104	FS上	4	144	TL上	1	185	FCT	10	227		3
25	1S	1	65	3S	9	105	FS上	5	145	TL上	2	186	FCT	11	228		4
26	1S	2	66	3S	10	106	FS上	6	146	TL上	3	187	FCT	12	229		5
27	1S	3	67	3S	11	107	FS上	7	147	TL上	4	188	FCT	13	230	客4	1
28	1S	4	68	3S	12	108	FS下	1	148	TL下	1	189	FCT	14	231		2
29	1S	5	69	4S	1	109	FS下	2	149	TL下	2	190	FCT	15	232		3
30	1S	6	70	4S	2	110	FS下	3	150	TL下	3	191	FCT	16	233		4
31	1S	7	71	4S	3	111	FS下	4	151	TL下	4	192	FC前	1	234		5
32	1S	8	72	4S	4	112	FS下	5	152	TW上	1	193	FC前	2	235	客5	1
33	1S	9	73	4S	5	113	FS下	6	153	TW上	2	194	FC前	3	236		2
34	1S	10	74	4S	6	114	FS下	7	154	TW上	3	195	FC前	4	237		3
35	1S	11	75	4S	7	115	1CL	1	155	TW上	4	196	F	1	238		4
36	1S	12	76	4S	8	116	1CL	2	156	TW下	1	197	F	2	239		5
37	1S	13	77	UH 71	1	117	1CL	3	157	TW下	2	198	F	3	240	客6	1
38	1S	14	78	UH 52	2	118	1CL	4	158	TW下	3	199	F	4	241		2
39	1S	15	79	UH 72	3	119	1CL	5	159	TW下	4	200	花F上	1	242		3
40	1S	16	80	UH 63	4	120	1CL	6	160	FC上	1	201	花F上	2	243		4
									161	FC上	2	202	花F下	1	244		5
												203	花F下	2			